


# MODEL: KP-SWM



## PARTS LIST (KP-SWM)

\*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART NO. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
001	92000101	BODY	1	504	91006601	HEX. SOC. HDLESS. BOLT	1				
002	92000201	HANDLE	1	505	91307001	HEX. SOC. HD. BOLT	2				
003	92000301	HANDLE GLEEVE	1	507	91005901	SPRING PIN	4				
004	92000401	LINK	1	508	91006901	HEX. SOC. HD. BOLT	2				
005	92000501	PIVOT PIN	1	509	91007001	HEX. SOC. HD. BOLT	4				
006	92000601	PIVOT SCREW	1	510	91007101	FLAT. HD. BOLT	2				
007	92000701	COVER	1	511	91007201	PIN**	4				
008	92000801	SPRING	1	512	91007301	PIN**	2				
010	92000901	ADJUSTMENT SCREW	1	513	91007401	HEX. SOC. HD. BOLT	2				
011	92001001	ADJUSTMENT NUT	1	514	91008701	HELI - COIL	1				
012	91002001	ADJUSTING ROD	1	515	91007501	SPRING PIN	2				
014	92001101	FRONT PLATE	1	516	91007601	FLAT. HD. SCREW	2				
015	91002301	RIGHT TEETH**	1	517	91007701	SPRING PIN	2				
016	91002401	LEFT TEETH**	1	518	91007801	FLAT. HD. BOLT	1				
017	91002501	TEETH SEAT**	2	519	91007901	LOCK NUT	1				
018	91002601	PLATE	2	520	91008001	LOCK NUT	6				
019	92001201	BLOCK	1	521	91008101	WASHER	4				
020	91002801	DRIVER**	1	522	92001601	HELI - COIL	1				
021	92001301	COVER UNIT	1	523	91008201	SPRING PIN	1				
022	91203001	DRIVER GUIDE UNIT**	1	524	91008501	BRACKET	1				
023	91003101	PLATE	2	525	91008601	FLAT. HD. BOLT	2				
024	91203201	MAGAZINE	1	526	91009001	FLAT. HD. BOLT	1				
025	91003301	ROD NUT**	2								
026	91003401	ROD**	2								
027	91003901	RIGHT PUSHER GUIDE**	1								
028	91003501	SPRING**	1								
029	91003601	ROOLER**	1								
030	91203701	PUSHER UNIT**	1								
032	92001401	MAGAZINE SEAT	1								
033	91004001	LEFT PUSHER GUIDE**	1								
039	91004101	WASHER	2								
501	92001501	SPRING PIN	2								
502	91005101	HEX. SOC. HD. BOLT	2								
503	91006501	ROD	2								