



MODEL : LNF-32AD



*B : APPLY LOCTITE 242

L11151 03/09/2012

PARTS LIST (LNF-32AD)

*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART NO. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
01	HS05080BW-16	HEX. SOC. HD. BOLT+SW	4	53	12105301	PUSHER	1				
03	11100302	CAP	1	54	12105401	SPRING**	1				
04	12100401	SEAL**	1	55	12105501	NAIL GUIDE LINER	1				
05	12100501	SPRING**	1	57	HS05080B-07	HEX. SOC. HD. BOLT	1				
06	OR13824N	O RING**	1	61A	12106101A	BRACKET ASSEMBLY	1				
07	11100702	CAP SEAL**	1	64	HS05080B-16	HEX. SOC. HD. BOLT	1				
08A	12100801A	HEAD VALVE ASM.	1	65	LN0500N	LOCK NUT	1				
11	OR31824N	O RING**	1	66	11106601	COVER	1				
13	OR22431N	O RING**	1	67	12106401	AIR PLUG	1				
14A-1	11001401A	DRIVER ASSEMBLY**	1	68	OR40030N	O RING**	1				
14A-2	11001402A	DRIVER ASSEMBLY**	1	71	US05080B-06	UM. HD. BOLT	1				
18	OR44431N	O RING**	1	72	FW050120B-10	FLAT WASHER	1				
19	11101902	CYLINDER	1	73	12103301	SEAL	1				
19-3	11101903	COLLAR	1	74	13907403	EXHAUST COVER	1				
20	11002001	BUMPER**	1								
21	OR28318N	O RING**	1								
23	11102309	BODY	1								
24	OR01919N	O RING**	2								
25	10902501	JOINT GUIDE	1								
26	11002601	SPRING	1								
27	11002702	GUIDE SAFETY LEVER	1								
31	11003101	SAFETY LEVER	1								
32	11103201	STEPPED PIN	2								
41	HS05080B-10	HEX. SOC. HD. BOLT	2								
42	HS05080BW-25	HEX. SOC. HD. BOLT+SW	2								
44	12104404	DRIVER GUIDE COVER	1								
45	12104501	SET PLATE	1								
46	HS04070B-12	HEX. SOC. HD. BOLT	2								
47	12104701	DRIVER GUIDE	1								
48	11004801	MAGAZINE COVER	1								
49	SS04070B-12	SET SCREW	1								
50	11005001	MAGAZINE	1								
51	HS04070BW-08	HEX. SOC. HD. BOLT+SW	4								
52	11005201	TAIL COVER	1								